


VX3085 BANNER: ASSEMBLY INSTRUCTIONS



- 1 Turn base over and remove pole.
- 2 Twist out both feet until facing forward.
- 3 Open out scissor section pole and insert into base.
- 4 Lift the top rail and pull to raise the graphic from the base.
- 5 lean the banner stand backwards and continue to extend the graphic.
- 6 Secure the extended graphic by locating the hook on the top rail and fitting onto the pole



Always handle graphic with care. Slowly feed graphic into cassette when retracting.